



The model VIS-8005 is a 1-Channel 315 MHz charcoal and silver remote supplied with a quick-disconnect key ring. This transmitter (remote) is designed for use with the VISIONIS VIS-8004 1 channel receiver. This transmitter (remote) has over 1,048,576 codes of programming which makes it virtually impossible of the codes being duplicated. The receiver programs each specific code; no unauthorized person can gain access to the system by reprogramming or duplicating the Transmitter (remote). This transmitter (remote) can be programmed locally into the memory of the receiver (VIS-8004).

Model No.	VIS-8005
Voltage	12/24V
Frequency	315 MHz
Current Draw	10Ma
Number of Buttons	1
Encoding Type	Fixed
Operating Distance	Up to 320 Feet (100M)
Compatible Receiver	VIS-8004
Remotes	Up to 20 Remotes are able to connect to one receiver
LED Transmission	LED Transmission: Blue LED light
Includes	Includes: 2 pieces of the 3v CR2016
Codes	Over 1,048,576 codes



Disclaimer: VISIONIS reserve the right to go ahead with any modifications of models or features or price without forewarning. All the information and specifications stated in this document are current at the time of publication. Attention: We are not responsible for the improper installation of this kit. If you are not handy with electrical equipment you should contact a professional electrician. You will also need to check with your local Fire authority to see if you need anything else to comply with local Fire Codes. We are not responsible for any damage or fees that can occur.



sales@visionistech.com



www.visionistech.com

Instructions to program a new Transmitter (remote):

Note: Before you start to program the Transmitter (remote) make sure you have the Receiver ready to be programmed. You may only use the Visionis Receiver model number VIS-8004.

- Each VIS-8004 Visionis receiver can program up to 20 Transmitters (remotes) (VIS-8005)
- Make sure that while you are programming the transmitter (remote) you have the remote in your hands ready to be programmed.
- Press the programming switch for 3 seconds or more. The channel's LED will start to flash quickly. This will indicate that it is in programming mode.
- When the LED light begins to Flash, Press the button of the Transmitter (remote) to be programmed one time. The receiver's Channel light will flash once to show that that the transmitter (remote) has been programmed successfully. After the transmitter (remote) has been programmed the receiver will automatically exit the programming

